

Upstand warm roof self adhered termination bar

1. Suitable sealant.
2. Termination bar or metal flashing.
3. RESITRIX SKW membrane self-adhered onto primed substrate and hot air welded onto field membrane.
4. Primer FG35.
5. Hot air weld.
6. RESITRIX SKW membrane self-adhered onto primed insulation.
7. ALUTRIX 600 Vapour Barrier self-adhered onto primed substrate. Not required when using existing roof as vapour barrier.
8. Recommended insulation installed as per the manufacturer's recommendations.

