

Welted drip warm roof self adhered

1. RESITRIX SKW adhered onto primed substrate and hot air welded onto lower layer.
2. Hot air weld.
3. RESITRIX SKW self-adhered to primed substrate.
4. Primer FG35.
5. Standoff batten.
6. Drip infill (6mm thick). It is recommended but not necessary to chamfer the face.
7. Oval nail sunk into timber batten.
8. ALUTRIX 600 Vapour Barrier self-adhered onto primed substrate. Not required when using existing roof as vapour barrier.
9. Recommended insulation

